

Studio Stands

Lay out the banner flat on the ground face down.

Position the CAPSULE so the LEG HOLE is facing down and towards the back of the banner.

Note: The back leg is the shorter rod.

Place all four ARMS in the CAPSULE while flat on the ground. Next insert the ARMS into the grommets.

Start with the two bottom ARMS first then as you insert the two top ARMS.

You will begin to add tension to the display. Once all four arms are in place, stand it up and insert the back leg.

Sizes

Large (34 x 86") - \$180

Medium (30 x 68") - \$135

Small (24 x 50") - \$90

