



# Interior Metal Faced Sign Installation Guide

## Materials Needed:

### Included:

Clear Silocone Adhesive (Liquid Nails)  
Double Stick Tape  
Paper Pattern

### Not Included:

Level  
Tape Measure  
Masking Tape  
Pen  
Thumb Tack

Measure the area to determine the exact placement of your sign letters. Make sure the area is clean and free of dust by wiping the surface with a clean, dry cloth. Always double check the pattern for accuracy before starting. Double check that all sign letters were delivered.

Tape one edge of the paper pattern to the installation surface with masking tape and unroll it. Level the pattern and tape the other edge to the installation surface. Securely tape the corners and sides to prevent movement.

Use a pen or thumb tack to indent corners/edges of the letters on the wall. The indentation marks will be used as a guide for letter placement. Partially peel back the pattern from one corner to insure your indentations are visible enough. Adjust indentation accordingly. Once the letters/logo have been marked remove the paper pattern from the wall.

Prepare the letters for installation by placing pieces of double stick tape on the backside of each letter. Add small dabs of the clear silicone adhesive to insure extra support.

Remove any backing from the adhesive or tape on each sign letter or logo element, and gently place them on the mounting surface. Making sure each sign letter is properly aligned, apply pressure to ensure a secure bond. After sign letters have been secured to the wall remove the protective film on the face of the sign letters.

**NOTE:** Temperature variations may cause some letter to differ from the template print. The level line would be the best guide in this situation.